

These ball flaps are different for each and every machine. They may require some finesse and trimming to be just right. They are usually not a direct replacement.

For the tapered version: Best to align the vertical center up as needed to your specification and trim the top and or bottom if need be.



Align C centered to your playfield. Trim by sanding or filing (be careful) A and B if needed. Then drill or punch your holes lastly.